

**STEP1. GETTING STARTED**

Before using the optical tag, the lock with rubber cushion should be in an open position.



**STEP2. SETTING THE LOCK OPEN**

To set the rubber cushion in an open position, please use the detacher DT4002. Insert the screw driver's metal head into the lock slot on the tag. Rotate the screw driver anticlockwise to set the rubber cushion into total open position.



**STEP3. APPLYING THE OPTICAL TAG**

When the rubber cushion is set in the open position, insert the glasses feet into the gap on the locking structure. To keep the comfort for a customer try-on, moving the optical tag close to the glasses frame is suggested.



**STEP4. SETTING THE TAG LOCKED**

To set a lock for the tag with an eyewear, please use DT4002 detacher. Insert the metal head of the detacher screw driver into the lock slot. Rotate the DT4002 clockwise, until the rubber cushion is fully closed.

